


- J - Beugel
- J - Bügel
- J - Support
- J - Bracket
- J - Konsole

Werkdruk : Max.10 bar  
 Betriebsdruck : Max.10 bar  
 Pression de service : Max.10 bar  
 Operating pressure : Max.10 bar  
 Presión : Max.10 barar  
 Ciśnienie Robocze : Max.10b



H	A	B	C	D
1820	100	170	770	1540
2020	100	170	870	1740

MONTAGEVOORSCHRIFT

MOUNTING INSTRUCTIONS

INSTRUCCIONES DE MONTAJE

ISTRUZIONI DI MONTAGGIO

MONTAGE-ANLEITUNG

INSTRUCTIONS DE MONTAGE

INSTRUKCJA MONTAŻU

# Handdoekbeugel VD

